




CONNECTOR PLATE - WIRING SIDE




OIL
PSI




FUEL
QTY




OIL
TMP




FUEL
PSI




EGT




CHT



AMPS



VOLTS



PIN ASSIGNMENTS

CHT AND EGT DO NOT REQUIRE POWER

FOR 28V CONNECT BALLAST RESISTOR TO PINS 1 AND 5